



Angle Cutting on the Router Boss



The base plate normally mounts perpendicular to the machine face. In this position the variable guides allow angled cuts at $\pm 10^\circ$ in 1° increments. For greater angles you can rotate the base plate 20° , 25° or 45° and also use the variable guides to adjust the cut angle up to 55° .



Threaded holes on box beam shown in black

